

1.1 CONCRETE UNIT MASONRY BLOCK FILLERS

A. Concrete Unit Masonry Block Filler:

1. Coronado; 946-11 Super Kote 5000 Commercial Latex Block Filler.
2. Kwal Paint; 5940 AccuGuard High Performance 100% Acrylic Block Filler.
3. Sherwin-Williams; PrepRite Interior/Exterior Block Filler B25W25.

1.2 EXTERIOR PRIMERS

A. Exterior Concrete and Masonry Primer:

1. Coronado; 48-11 Elast-O-Meric Acrylic Masonry Sealer.
2. Kwal Paint; 5801 Epotilt Epoxy Modified 100% Acrylic Primer.
3. Kwal Paint; 5862 EMBASSY WB 100% Acrylic Primer Undercoat.
4. Sherwin-Williams; Loxon Exterior Masonry Acrylic Primer A24W300.
5. Sherwin-Williams; A-100 Latex Exterior Wood Primer B42W41.

B. Exterior Gypsum Soffit Board Primer:

1. Coronado; 8-11 Supreme Acrylic Bonding Primer.
2. Kwal Paint; 5862 EMBASSY WB 100% Acrylic Primer Undercoat.
3. Sherwin-Williams; A-100 Exterior Latex Wood Primer B42W41.

C. Exterior Wood Primer for Acrylic Enamels:

1. Coronado; 8-11 Supreme Acrylic Bonding Primer.
2. Kwal Paint; 5810 G-Prime Premium 100% Acrylic Primer.
3. Sherwin-Williams; A-100 Exterior Latex Wood Primer B42W41.

D. Exterior Wood Primer for Alkyd Enamels:

1. Coronado; 5-11 Supreme Collection Oil House Paint Primer.
2. Kwal Paint; #9200 AccuPro Duoprime Alkyd Wood Primer.
3. Sherwin-Williams; A-100 Exterior Latex Wood Primer B42W42.

E. Exterior Ferrous-Metal Primer:

1. Coronado; 35-147 Rust Scat Alkyd Metal Primer.
2. Kwal Paint; 9210 Accu-Pro Rust Inhibiting Alkyd Metal Primer.
3. Sherwin-Williams; Kem Kromik Universal Metal Primer B50NZ6/B50WZ1.

F. Exterior Galvanized Metal Primer:

1. Coronado; 36-11 Rust Scat Latex Metal Primer.
2. Kwal Paint; 5810 Ambassador G-Prime Latex Metal Primer.
3. Sherwin-Williams; Galvite HS Paint B50WZ3.

G. Exterior Aluminum Primer under Acrylic Finishes:

1. Coronado; 36-11 Rust Scat Latex Metal Primer.
2. Kwal Paint; 5820 W.B. Industrial DTM Primer.
3. Sherwin-Williams; DTM Acrylic Primer/Finish B66W1.

H. Exterior Aluminum Primer under Alkyd Finishes:

1. Coronado; 180-11 High Performance Acrylic Metal Primer.

2. Kwal Paint; 5820 W.B. Industrial DTM Primer.
3. Sherwin-Williams; DTM Wash Primer B71Y1.

1.3 INTERIOR PRIMERS

- A. Interior Concrete and Masonry Primer:
 1. Coronado; 40-11 Super Kote 5000 Latex Primer-Sealer.
 2. Kwal Paint; 0800 Accu-Tone Hi-Hide PDQ Sealer.
 3. Sherwin-Williams; PrepRite Masonry Primer B28W300.
- B. Interior Gypsum Board Primer:
 1. Coronado; 40-11 Super Kote 5000 Latex Primer-Sealer.
 2. Kwal Paint; 0890 Accu-Pro Sandable Drywall Primer.
 3. Sherwin-Williams; PrepRite 200 Latex Wall Primer B28W200 Series.
- C. Interior Plaster Primer:
 1. Coronado; 40-11 Super Kote 5000 Latex Primer-Sealer.
 2. Kwal Paint; 0800 Accu-Tone Hi-Hide PDQ Sealer.
 3. Sherwin-Williams; PrepRite 200 Latex Wall Primer B28W200 Series.
- D. Interior Wood Primer for Acrylic-Enamel and Semi-gloss Alkyd-Enamel Finishes:
 1. Coronado; 7-11 Super Kote 5000 Alkyd Primer Undercoat.
 2. Kwal Paint; 5862 Embassy E-Z Sand Acrylic Primer.
 3. Sherwin-Williams; PrepRite Wall and Wood Primer B49W200 Series.
- E. Interior Wood Primer for Full-Gloss Alkyd-Enamel Finishes:
 1. Coronado; 7-11 Super Kote 5000 Alkyd Primer Undercoat.
 2. Kwal Paint; 4200 Accu-Pro Fast Dry Alkyd Undercoat.
 3. Sherwin-Williams; PrepRite Wall and Wood Primer B49W200 Series.
- F. Interior Ferrous-Metal Primer:
 1. Coronado; 35-147 Rust Scat Alkyd Metal Primer.
 2. Kwal Paint; 9210 Accu-Pro Rust Inhibiting Alkyd Metal Primer.
 3. Sherwin-Williams; Kem Kromik Universal Metal Primer B50NZ6/B50WZ1.
- G. Interior Zinc-Coated Metal Primer:
 1. Coronado; 36-11 Rust Scat Acrylic Metal Primer.
 2. Kwal Paint; 5810 Ambassador G-Prime Latex Metal Primer.
 3. Sherwin-Williams; Galvite HS B50WZ30.

1.4 EXTERIOR FINISH COATS

- A. Exterior Flat Acrylic Paint:
 1. Coronado; 8-Line Supreme Acrylic Latex Flat.
 2. Kwal Paint; 6300 Accu-Pro 100% Acrylic Flat Finish.
 3. Sherwin-Williams; A-100 Exterior Latex Flat House & Trim Paint A6 Series.
- B. Exterior Low-Luster Acrylic Paint:
 1. Coronado; 408-Line Supreme Acrylic Satin Exterior.

2. Kwal Paint; 7100 Liquid Vinyl 100% Acrylic Satin.
3. Sherwin-Williams; A-100 Exterior Latex Satin House & Trim Paint A82 Series.

C. Exterior Semigloss Acrylic Enamel:

1. Coronado; 12-Line Supreme Acrylic Semi-Gloss.
2. Kwal Paint; 3200 Ambassador 100% Acrylic Semi-Gloss Block Resistant Enamel.
3. Sherwin-Williams; A-100 Latex Gloss A8 Series.

D. Exterior Full-Gloss Acrylic Enamel for Concrete, Masonry, and Wood:

1. Coronado; 414 Super Kote 5000 Acrylic Gloss Enamel.
2. Kwal Paint; 8400 Ambassador 100% Acrylic Gloss Block Resistant Enamel.
3. Sherwin-Williams; SuperPaint Exterior High Gloss Latex Enamel A85 Series.

E. Exterior Full-Gloss Acrylic Enamel for Ferrous and Other Metals:

1. Coronado; 80 Line Rust Scat Acrylic Latex High Gloss Enamel.
2. Kwal Paint; 8300 W.B. Industrial DTM Gloss Enamel.
3. Sherwin-Williams; DTM Acrylic Coating Gloss (Waterborne) B66W100 Series.

F. Exterior Full-Gloss Alkyd Enamel:

1. Coronado; 123 Line Super Kote 5000 High Gloss Alkyd Enamel.
2. Kwal Paint; 9800 Accu-Pro Alkyd Gloss Enamel.
3. Sherwin-Williams; Industrial Enamel B-54 Series.

1.5 INTERIOR FINISH COATS

A. Interior Flat Acrylic Paint:

1. Coronado; 28 Line Super Kote 5000 Latex Flat Paint.
2. Kwal Paint; 0910 Accu-Pro Velva Sheen Interior Flat.
3. Sherwin-Williams; ProMar 200 Interior Latex Flat Wall Paint B30W200 Series.

B. Interior Low-Luster Acrylic Enamel:

1. Coronado; 30-Line Super Kote 5000 Latex Eggshell Enamel.
2. Kwal Paint; 2100 Accu-Pro PC Latex Eggshell.
3. Sherwin-Williams; ProMar 200 Interior Latex Egg-Shell Enamel B20W200 Series.

C. Interior Semi-gloss Acrylic Enamel:

1. Coronado; 32-Line Super Kote 5000 Latex Semi-Gloss Enamel.
2. Kwal Paint; 3000 Accu-Pro Latex Semi-Gloss Enamel.
3. Sherwin-Williams; ProMar 200 Interior Latex Semi-Gloss Enamel B31W200 Series.

D. Interior Full-Gloss Acrylic Enamel:

1. Coronado; 414 Line Super Kote 5000 Acrylic High Gloss Enamel.
2. Kwal Paint; 8400 Ambassador 100% Acrylic Gloss Enamel.
3. Sherwin-Williams; ProMar 200 Interior Latex Gloss Enamel B21W201.

E. Interior Semigloss Alkyd Enamel:

1. Coronado; 27-Line Super Kote 5000 Alkyd Semi-Gloss Enamel.
2. Kwal Paint; 4600 Accu-Pro Alkyd Semi-Gloss.
3. Sherwin-Williams; ProMar 200 Interior Alkyd Semi-Gloss Enamel B34W200 Series.

- F. Interior Full-Gloss Alkyd Enamel:
 - 1. Coronado; 123 Line Super Kote 5000 High Gloss Alkyd Enamel.
 - 2. Kwal Paint; 9800 Accu-Pro Alkyd Gloss.
 - 3. Sherwin-Williams; ProMar 200 Alkyd Gloss Enamel B35W200 Series.

1.6 INTERIOR WOOD STAINS AND VARNISHES

- A. Interior Wood Stain:
 - 1. Coronado; 3601-Line Quick-Seal Alkyd Stain.
 - 2. Kwal Paint; 8709 Woodkraft Semi-Transparent Stain.
 - 3. Sherwin-Williams; Wood Classics Interior Oil Stain A-48 Series.
- B. Clear Sanding Sealer:
 - 1. Coronado; 81-10 Dual Seal.
 - 2. Kwal Paint; 4048 Woodkraft Sealer/Finish Satin.
 - 3. Sherwin-Williams; Wood Classics Fast Dry Sanding Sealer B26V43.
- C. Interior Alkyd- or Polyurethane-Based Clear Satin Varnish:
 - 1. Coronado; 67-100 Polyurethane Liquid Plastic Satin Varnish.
 - 2. Kwal Paint; 4039 Woodkraft Satin Varnish.
 - 3. Sherwin-Williams; Wood Classics Fast Dry Oil Varnish, Satin A66-300 Series.
- D. Interior Waterborne Clear Satin Varnish:
 - 1. Coronado; 70-10 Aqua-Plastic Urethane Clear Satin.
 - 2. Kwal Paint; 6840 Woodkraft Acrylic Urethane Satin.
 - 3. Sherwin-Williams; Wood Classics Waterborne Polyurethane Satin, A68 Series.
- E. Interior Waterborne Clear Gloss Varnish:
 - 1. Coronado; 70-10 Aqua-Plastic Urethane Clear Gloss.
 - 2. Kwal Paint; 6820 Woodkraft Acrylic Urethane Gloss.
 - 3. Sherwin-Williams; Wood Classics Waterborne Polyurethane Gloss, A68 Series.